



Numbered stations indicate 2'x2' pads for columns
with 4' spacing between pads